

Mounting instruction



AIRCELL®7

N-Connector, male (crimp) / Item. No.: 7371

Required tools :

- 1 x Cutter knife
- 1 x Wire cutter
- 1 x Crimp insert HEX 0.324"
- 1 x Crimp insert HEX 0.1"

1



Cut off the cable end at right angles.

2



Push the crimp sleeve onto the cable and strip it to approx. 15 mm up to the copper braid.

3



Push the copper braid backwards and unscrew the core of the cable, maintaining 9 mm of the dielectric. The soul itself has to be shortened to 5 mm

4



The inner lift is pushed over the core and crimped with 0.1 inch at the back.

5



The plug is plugged in with the dielectric in the socket. Subsequently, the copper braid is suitably shortened with a side cutter and the crimp sleeve is over-stretched.

6



Finally, the crimp sleeve is crimped at 0.324 inches.