

# Mounting instruction

## Ecoflex<sup>®</sup> 10, Aircom<sup>®</sup> Premium UHF-Connector / Art. No.: 7378



### Required tools :

- 1 x open-ended spanner 17 mm
- 1 x open-ended spanner 18 mm
- 1 x Cutter knife



Cut off cable tail right-angled.



Move the nut, clamping ring and rubber washer over the cable tail.



Remove 17 mm of the outer sheath with a knife.



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.



Remove the copper foil and the dielectric with a knife.



The prepared cable tail has to be carefully inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners. A small split should remain visible between clamping nut and connector housing.



Solder inner conductor at the tip carefully.