

Mounting instructions




AIRCELL® 7

SMA-Plug, crimp/solder item. no.: 7387

Required tools:

- 1 x Cutter knife
- 1 x scissors
- 1 x soldering iron/ station
- 1 x screwdriver
- 1 x Crimping pliers, crimping insert size .324



1 Cut off cable tail right-angled. Move the crimp-cover and the cable sleeve over the cable head.



2 Remove 12 mm of the outer sheath with the cutter knife.



3 Bend the copper mesh at a right angles. Remove 5 mm of the copper foil with the cutter.



4 Solder the inner conductor to the center contact.



5 Crimp the crimp jacket with a crimp tool; herewith the copper braid will be trapped between the crimp jacket and the connector housing.



Crimp the crimp jacket with a crimp tool; herewith the copper braid will be trapped between the crimp jacket and the connector housing.