

# Mounting instruction

## AIRCELL® 5

SMA-RP-Connector, Crimp Male / Art. Nr.: 7755



### Required tools :

- 1 x Cutter knife
- 1 x Wire cutter
- 1 x Crimp insert 0.213" (5,41 mm)
- 1 x Crimp insert 0.043" (0,86 mm)

1



Cut off cable tail right-angled. Move the crimp sleeve over the cable tail.

2




Remove 12 mm of the outer sheathing with a cutter knife. Bend copper braid upwards right-angled.

3



Remove 4 mm of the copper foil with a cutter knife.

4



Remove 2 mm of the foamed dielectric with a cutter knife.

5



Put the inner pin on to the inner conductor and solder or crimp it.

6



Insert the so prepared cable end into the connector housing as far it goes (click). Cut off the copper braid and move the crimp sleeve forward.

7



Crimp the crimp sleeve with a crimp tool; herewith the copper braid will be clamped between the socket housing and the crimp sleeve.