









Mounting instruction

ECOFLEX® 10 PLUS HTX

N-Connector, solderless / Art. Nr.: 7369



<p>1</p>  <p>Cut off cable tail right-angled.</p>	<p>2</p>  <p>Move the nut, clamping ring and rubber washer over the cable tail.</p> <p>Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.</p>
<p>3</p>  <p>Remove 6 mm of the outer sheath with a knife.</p>	<p>4</p>  <p>Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop.</p>
<p>5</p>  <p>Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.</p>	<p>6</p>  <p>Remove the copper foil and the dielectric with a knife. The inner conductor must stay absolutely round. Remove burr from sharp edges.</p>
<p>7</p>  <p>Move inner pin into the teflon-isolator. Subsequently, clip inner pin carefully onto the inner conductor.</p> <p>Hint: The inner conductor can be prepared with just a slim film of Vaseline, before attaching the inner pin. This improves the attenuation of intermodulation and prevents corrosion.</p>	<p>8</p>  <p>The prepared cable tail has to be inserted into the housing until stop. Hold the housing and tighten the clamping nut finger tight with two open-ended spanners 17/18 mm.</p> <p>A small split should remain visible between clamping nut and connector housing.</p>